


First operation for **USS-210** controllers

For our USB stick controllers you must first download and install the Windows USB driver **USBXpress_Drivergeneric.zip** located on our website page here:

<https://plequipment.com/product/uss-210-usb-stick-stepper-controller-motor-driver>

We recommend using a USB extension cable between the controller and your PC. When the **USS-210** controller is inserted in the USB port, if the USB driver was installed correctly, it will be listed in the Windows Device Manager as in the screen capture below.



From the same webpage you can download the **USS-210_QUICKSTART** manual which will further guide you on how to operate the controller.

DEMO programs written in **Visual Basic** and **LabView** (32bit version) are also available there under the names **USS-210_HOST.zip** and **USS-210_LV_2011.zip**.